


---

## Zehnder Yucca Asym




---




























---




Instrukcja montażu

---























**Attention:**  
If this towel radiator is to be installed with an immersion heater, then please observe the installation instructions supplied with the immersion heater.






**Attention:**  
Please observe the installation  
instructions of the immersion heater  
supplied with this unit.



---

## Zehnder Yucca



---



---

Instrukcja montażu - konsole


---



Chroń powierzchnię!




1



2 Nm




2



min. 80



3




max. 95


3.1





4




4.1




4.1





H	DMP	L
908	720	500 / 600 / 800
1340	1152	
1772	1584	



H	DMP	L
882	694	378 / 478 / 578
1304	1116	
1736	1548	