

---

## Zehnder Klaro

---




---

## Instrukcja montażu




---

Type PO(S90)/P34

Type PO(S90)-05




40004162  
Copyright by PBO 06/19




Type PO(S90)


L	300	450	500	600	750
K	80	100	100	100	100




Type 34



Type PO(S90)-05




Type PO(S90)M Type PO(S90)E, PO(S90)E-RF




Type PO(S90)M

L	300	450	500	600	750
K	80	100	100	100	100



Type PO(S90)E

L	400	500
---	-----	-----



Type PO(S90)E-RF

